

### Introduction

The **NP-STRAIN-1** is an intelligent general purpose strain gauge interface suitable for direct connection to strain gauges and load cells. The device connects to any suitable logger supports SDI-12 digital communications and is fully integrated into the free Keynes Controls Q-LOG data display and recording software.

The product is available as a stand-alone PCB for inclusion into 3rd party products or as a complete sensor complete with an enclosure.

The **NP-STRAIN-1** is User Programmable and can supply results in both raw or engineering unit format. A precision temperature sensor input is supplied for applications where compensation is required.


The sensor monitors the bridge excitation during the measurement and compensates automatically for any excitation variation during the data conversion process.

### OEM Applications

The NP-Strain-1 PCB can be supplied customised for third party applications. The PCB can be changed to allow for screw hole PCB mounting, choice of termination and pre-set configurations.

### Further Information

The **NP-STRAIN-1** strain can be used to provide force on a strain gauge based load cell using the following formula in Q-Log.



$$F = \frac{(e_o)(F_{fs})}{\left(\frac{mV}{V}\right)(E_x)}$$

F units Newtons


### Features

- Support for 120 to 1 K Ohm Gauges
- Load Cells
- External bridge completion
- Precision Temperature Sensor
- User Programmable Scaling Factors
- SDI-12 Digital Communications
- Extended SDI-12 Address Support: 0-9 , a-z
- 16 Bit Precision ADC
- Low Power - minimised self heating effect
- Engineering and raw data values
- Fully Integrated into Q-Log Software
- Firmware upgrade facility

The image opposite shows both the NP-STRAIN-1 circuit board and the waterproof housing.

The sensor has been designed for operation in harsh environments and still has the ability to be easily installed in the field.

No special installation tools or plugs are required simply since all signal and sensor cables simply push into the cable clamps mounted on the front and back of the unit.



Q-LOG Device Setup Window

### Download a copy of Q-Log

Further information at:


<http://www.aquabat.net/QLOGFree/qlogv2.html>

### Installation & Operation

The installation and operation of the NP-Strain-1 sensor is straight forward.

### Bridge Type

Connect the strain gauges and bridge completion resistors to the sensor input port, see Figures 7, 8 through 10 for sample wiring options.



### Network Connection

Connect the SDI-12 digital port on the sensor to the SDI-12 port on the USB-SDI12 media convertor or SDI-12 port on a suitable data logger.


Default ID = 0 unless specified on the sensor.

### Physical Installation


Mount the NP-Strain-1 interface as close to the gauge/load cell is as practical for minimum noise and optimum results

### Wiring Diagram

The image opposite shows the wiring schematic for connection the NP-Strain-1 onto a SDI-12 network.



### Network Connection Diagram



# Technical Specifications

Specifications are accurate at the time of publishing but can be changed without notice.

<b>Power Supply</b>	10 -18 V
<b>Current</b>	2 mA at acquisition 10 uA standby
<b>Input Range</b>	+/- 8mV Other ranges on request
<b>SDI-12 Port</b>	1 x Port Version 1.03
<b>Max update rate</b>	1 sec
<b>Cable Clamp Size</b>	1 mm diameter
<b>Bridge Excitation</b>	3.3 V DC
<b>Raw Value</b>	Raw data mV/V
<b>Engineering Value</b>	micro-strain, mV/V User defined
<b>Range</b>	User defined, depends on sensor installed
<b>Temp Sensor</b>	Thermistor
<b>Thermistor Type</b>	3 K EC95 F type material 10K 3A1 Betatherm
<b>Calibration</b>	Steinhart-Hart Built Pre-defined Set at manufacture
<b>Accuracy</b>	0.05 Deg -8 to 25 Deg C
<b>Range</b>	-30 to + 60 Deg
<b>Units</b>	Deg C / Deg F user select
<b>RMS Noise</b> (Typical values)	less than 1 uV/V less than 0.01 Deg C
<b>PCB Dimension</b>	
<b>Length</b>	60 mm
<b>Width</b>	19.7 mm
<b>Max depth</b>	11.2 mm
<b>Cable Entry</b>	1 m Screw terminal
<b>Number Channels</b>	1
<b>Gauge Resistance</b>	120 - 1K Ohm
<b>Gauge Factor</b>	User Defined
<b>ADC</b>	16 Bit
<b>Statistics</b>	
<b>Strain</b>	Max, Min
<b>Temp</b>	Max, Min

## Example AquaLOG SDI-12 Commands

- [D] OM! OD0! - get data ID=0 returns 2 values strain, temp
- [F] OM! OD1! - get Max Strain, temp values returns 4 values into cells F .. I
- OMM1! - reset max strain for sensor ID=0

Command	Response	Description
aM!	a0tt2	2 values in time tt given by stats
aD0!	a+0.123+25.5	Strain and temperature values
aD1!	a+0.1299+0.1201+25.9+25.0	Statistical values max S, min S, max T, Min T
al!	a13KEYNES COPRESR001	Identification string
aXUTu!	au	Temperature units u=0 → Celsius, u=1 → Fahrenheit with read back
aXCn,xxxx	an,xxxx	Calibration data (No temp compensation - default) E = [0] + [1]*s with read back. s is in mV/V E is in micro-strain
aXFt,nn,xxxx!	at,nn,xxxx	Ensemble Averaging Command t → filter type (should be 0 - mean only) nn → number of filtered values 1 to 12 xxxx → interval between beasurment * 200ms
aXTHMT(0..1)	a+0/1	Thermistor type selection 0 → default = 3.3 K <b>Material type F - Model EC95</b> 1 → 10 K Ohm <b>Model 10K3A1 Betatherm</b>

## Bridge Zero Offset Correction

The NP-Strain-1 sensor does not zero correct the bridge and assumes the User will correct the error in post processing of the data.

## Temperature coefficient of Gauge Factor (TCGF)

This is the change of sensitivity of the device to strain with change in temperature. This can be compensated for in the calibration equations but it is recommended to be post process corrected in any data analysis.

## PC / Laptop Data Acquisition Solutions

The image below shows a simple PC based strain gauge data acquisition application created using the NP-Strain interface cards and the Keynes Control USB media converter.





Fig-5

Physical Dimensions

## Strain Equations

The following equations are used by the NP-Strain-1 card to determine the measured strain.

$$\epsilon = \frac{4(e_o)}{(GF)3.3} \quad \text{1/4 bridge strain gauge}$$

$$\epsilon = \frac{2(e_o)}{(GF)3.3} \quad \text{1/2 bridge strain gauge}$$

$$\epsilon = \frac{(e_o)}{(GF)3.3} \quad \text{Full bridge strain gauge}$$


## Default Configuration

The NP-Strain-1 interface uses the 3 K Ohm thermistor by default. The following command can be used to test the NP-Strain-1 sensor.


Start measurement: **OM!** returns 012 - 1 sec response 2 values  
**OD0!** returns 0+strain+temp

## Bridge Circuit Options


The images below show how the different bridge options are connected to the NP-Strain-1 card.




Example circuit shows a full (N=4) bridge strain gauge and thermistor



Example circuit shows a half (N=2) bridge strain gauge and thermistor.



Example circuit shows a quarter (N=1) bridge strain gauge and thermistor.



Example circuit shows a half bridge strain gauge (N=2) with 3 wire interface - reduces cable length effects.

### Strain calculated using 1, 2 or 4 active arms

$$\epsilon = \frac{4(e_o)}{(N)(GF)E_x}$$

N = 4 for full bridge  
2 for half bridge  
1 for quarter bridge

$E_x$  = Bridge Excitation = 3.3 V  
 $\epsilon$  = strain  
 $e_o$  = Output Voltage  
N = Number of effective arms  
GF = Gauge Factor

## Supported SDI-12 Commands

## Example Calibration Commands

aXC0,offset! aXC1,scale!

**Example** - Set scale factor for device with ID = 3 to 4.5 and offset = 2.78

SDI-12 Commands are

3XC1,4.35! 3XC0,2.78!

The output from the device is calculated by

Output ( Eng Units) = Scale.  $V_{in}$  - Offset

## Part Numbers

- NP-Strain-1-SDI-12** Strain gauge interface - SDI12 digital network option
- NP-Strain-1-RS485** Strain gauge interface - RS-485 digital network option

Copyright Keynes Controls © 2014-2015

No part of this document can be recreated without Permission of Keynes Controls Ltd

This document is accurate at the time of print. Keynes Controls Withold the right to make changes at any time without notification.